


OPTIONS & ACCESSORIES

EasyDesk Welding

Configure a precise, production-ready weld cell.

Ten options for your EasyDesk Welding.



Configure your welding cell.

OPTIONS 01-05 / 10



01 EasyDesk Safety Enclosure 2-walls

Fits all the EasyDesk versions

ED-1002-SE



**02 EasyDesk Safety Enclosure
2 walls with extension**

Fits all the EasyDesk Tray and Alu

ED-1003-SE



**03 EasyDesk Enclosure -
Compact Enclosed Robot Cell**

Fits all the EasyDesk versions

ED-1001-EC



04 Wheels for EasyDesk

Caster wheel with foot locker

GD-Wheels



05 Extra Front/Rear dock for larger robots

Extra Front/Rear dock when mounting larger robots

PFF-1002-05

Configure your EasyDesk Welding.

Choose enclosures, mounting and mobility options.

easyrobotics.biz


info@easyrobotics.dk

OPTIONS & ACCESSORIES

EasyDesk Welding

Configure a precise, production-ready weld cell.

Ten options for your EasyDesk Welding.



Configure your welding cell.

OPTIONS 06-10 / 10



06 Angle for EasyDesk 30 degrees

30 degrees angle

ER-Angle-30



07 Angle for EasyDesk 45 degrees

45 degrees angle

ER-Angle-45



08 Handle for EasyDesk

Handle to push/pull the EasyDesk

ER-Handle



09 Yellow Scanner cover

Cover for laser scanner

SC-1000



RAL

10 Custom RAL code

RAL Code XXXXX

RAL-XXXX

Adapter Plates: Please refer to the separate Adapter Overview to find the appropriate adapter plate for the specific robot being used. [Click here](#)

Custom RAL colour swatches are illustrative.

Configure your EasyDesk Welding.

Choose enclosures, mounting and mobility options.

easyrobotics.biz

info@easyrobotics.dk