


OPTIONS & ACCESSORIES

EasyPalletizer Basic

Configure the platform around your process.

Five options for your EasyPalletizer Basic.



Configure your palletizer.

5 OPTIONS



01 EasyPalletizer Basic with fixed pedestal 850mm

H: 850 mm, W: 870, L: 1350, Wt: 200 kg,
For 2 pallets with two adjustable Pallet Grid, Fixed pedestal 835 mm

PTB-1002



02 EasyPalletizer Basic with fixed pedestal 1200mm

H: 850 mm, W: 870, L: 1350, Wt: 200 kg,
For 2 pallets with two adjustable Pallet Grid, Fixed pedestal 1200 mm

PTB-1003



03 EasyPalletizer Basic with Lifting column 876-1776mm

H: 876 mm, W: 870, L: 1350, Wt: 200 kg,
For 2 pallets with two adjustable Pallet Grid, Lifting column 876-1776mm

PTB-1004



04 Yellow Scanner cover

Cover for laser scanner

SC-1001



05 Custom RAL code

RAL Code XXXXX

RAL-XXXX

Adapter Plates: Please refer to the separate Adapter Overview to find the appropriate adapter plate for the specific robot being used. [Click here](#)

Custom RAL colour swatches are illustrative.

Configure your EasyPalletizer Basic.

Choose your pedestal or lifting column, scanner cover and RAL colour.

easyrobotics.biz

info@easyrobotics.dk