

OPTIONS & ACCESSORIES

Easy Pedestal


Stable base. Flexible configuration.

Nine options for your EasyPedestal Base & Pro.



Make it work for you.

OPTIONS 01-04 / 09



**01 Table for EasyPedestal Base & Pro
Workspace 600x400 mm**

Workspace 600x400 mm, max weight per table 60 kg

ER-1000-T



**02 Linear Extender for Pedestal
Base and Pro 100 mm**

Adapt the mounting height 100 mm

ER-1006-100



**03 Linear Extender for Pedestal
Base and Pro 200 mm**

Adapt the mounting height 200 mm

ER-1006-200



**04 Linear Extender for Pedestal
Base and Pro 300 mm**

Adapt the mounting height 300 mm

ER-1006-300

Configure your pedestal.

Choose tables, height and angle extenders, scanner cover and colour.

easyrobotics.biz

info@easyrobotics.dk

OPTIONS & ACCESSORIES

Easy Pedestal


Stable base. Flexible configuration.

Nine options for your EasyPedestal Base & Pro.



Make it work for you.

OPTIONS 05-09 / 09

	05 Angular Extender for Pedestal Base and Pro 15 degrees Set the mounting angle 15 degrees	ER-1007-15
	06 Angular Extender for Pedestal Base and Pro 30 degrees Set the mounting angle 30 degrees	ER-1007-30
	07 Angular Extender for Pedestal Base and Pro 45 degrees Set the mounting angle 45 degrees	ER-10007-45
	08 Yellow Scanner cover Cover for laser scanner	SC-1001
	09 Custom RAL code RAL Code XXXXX	RAL-XXXX

Adapter Plates: Please refer to the separate Adapter Overview to find the appropriate adapter plate for the specific robot being used. [Click here](#)

Custom RAL colour swatches are illustrative.

Configure your pedestal.

Choose tables, height and angle extenders, scanner cover and colour.

easyrobotics.biz

info@easyrobotics.dk