WELDING CELL CONFIGURATION

EasyWelding Turn Table




Continuous two-sided robotic welding.

Four options for your EasyWelding Turn Table.

Make it work for you.


4 OPTIONS



01 Angle for EasyDesk and ProFeeder 30 degrees

30 degrees angle

ER-Angle-30



02 Angle for EasyDesk and ProFeeder 45 degrees

45 degrees angle

ER-Angle-45



03 Yellow Scanner cover

Cover for laser scanner

SC-1000

RAL

04 Custom RAL code

RAL Code XXXXX

RAL-XXXX

Adapter Plates: Please refer to the separate Adapter Overview to find the appropriate adapter plate for the specific robot being used. **Click here**

Supplied angle images are identical and illustrative.
Custom RAL colour swatches are illustrative.

Configure the welding workflow.

Choose mounting angles, scanner cover and colour.

easyrobotics.biz

info@easyrobotics.dk