

MAKE IT WORK FOR YOU

FlexiGuard Tending Station

Robust access. Controlled guarding.

Two options for your FlexiGuard Tending Station.



Make it work for you.

2 OPTIONS



01 **Yellow Scanner cover**

SC-1000



RAL

02 **Custom Ral code**

Ral CodeXXXXX

RAL-XXXX

Adapter Plates: Please refer to the separate Adapter Overview to find the appropriate adapter plate for the specific robot being used. [Click here](#)

Custom RAL colour swatches are illustrative.

Configure your FlexiGuard station.

Choose scanner protection and your custom RAL colour.

easyrobotics.biz

info@easyrobotics.dk