

MAKE IT WORK FOR YOU

ProFeeder Alu


Your tooling. Your cell configuration.

Seven ways to tailor your ProFeeder Alu.



Make it work for you.

OPTIONS 01-04 / 7



01 Wheels for ProFeeder Tray / Alu

Caster wheel with foot locker

GD-Wheels



02 Extra Front/Rear dock for larger robots

Extra Front/Rear dock when mounting larger robots

PFF-1002-05



03 Angle and ProFeeder 30 degrees

30 degrees angle

ER-Angle-30



04 Angle for ProFeeder 45 degrees

45 degrees angle

ER-Angle-45

Configure your ProFeeder Alu.

Choose mounting, mobility and accessory options.

easyrobotics.biz

info@easyrobotics.dk

MAKE IT WORK FOR YOU

ProFeeder Alu


Your tooling. Your cell configuration.

Seven ways to tailor your ProFeeder Alu.



Make it work for you.

OPTIONS 05-07 / 7



05 Handle for ProFeeder series

Handle to push/pull the ProFeeder

ER-Handle



06 Yellow Scanner cover

Cover for laser scanner

SC-1000



RAL

07 Custom RAL code

RAL Code XXXXX

RAL-XXXX

Adapter Plates: Please refer to the separate Adapter Overview to find the appropriate adapter plate for the specific robot being used. [Click here](#)

Custom RAL colour swatches are illustrative.

Configure your ProFeeder Alu.

Choose mounting, mobility and accessory options.

[easyrobotics.biz](mailto:info@easyrobotics.dk)

info@easyrobotics.dk