

OPTIONS & ACCESSORIES

ProFeeder Flex


Mobile. Docked. Configurable.

Five ways to configure your ProFeeder Flex.



Make it work for you.


5 OPTIONS



01 Table for ProFeeder Flex

Workspace 600 x 400 mm;
max. weight per table 60 kg.

PFF-1002-06



02 Extra floor docking plate (2 pcs)

Two extra docking plates for ProFeeder Flex

PFF-1002-04



03 Extra Front/Rear dock for larger robots

Extra Front/Rear dock when mounting larger robots

PFF-1002-05



04 Yellow Scanner cover

Cover for laser scanner

SC-1001



RAL

05 Custom RAL code

RAL Code XXXXX

RAL-XXXX

Adapter Plates: Please refer to the separate Adapter Overview to find the appropriate adapter plate for the specific robot being used. [Click here](#)

Custom RAL colour swatches are illustrative.

Configure your ProFeeder Flex.

Choose work tables, docking and accessory options.

easyrobotics.biz

info@easyrobotics.dk