

OPTIONS & ACCESSORIES

ProFeeder S


Your capacity. Your configuration.

Six ways to configure your ProFeeder S.



Make it work for you.

OPTIONS 01-03 / 6



01 Wheels for ProFeeder series

Caster wheel with foot locker

GD-Wheels



02 Angle for ProFeeder 30 degrees

30 degrees angle

ER-Angle-30



03 Angle for ProFeeder 45 degrees

45 degrees angle

ER-Angle-45

Configure your ProFeeder S.

Choose mounting, mobility and accessory options.

easyrobotics.biz

info@easyrobotics.dk

OPTIONS & ACCESSORIES

ProFeeder S


Your capacity. Your configuration.

Six ways to configure your ProFeeder S.



Make it work for you.

OPTIONS 04-06 / 6



04 Handle for ProFeeder series

Handle to push/pull the ProFeeder

ER-Handle



05 Yellow Scanner cover

Cover for laser scanner

SC-1000



RAL

06 Custom RAL code

RAL Code XXXXX

RAL-XXXX

Adapter Plates: Please refer to the separate Adapter Overview to find the appropriate adapter plate for the specific robot being used. [Click here](#)

Custom RAL colour swatches are illustrative.

Configure your ProFeeder S.

Choose mounting, mobility and accessory options.

[easyrobotics.biz](mailto:info@easyrobotics.dk)

info@easyrobotics.dk